PROFESSIONAL HOODS





Monogram 42" Custom Hood Insert required for installation.

UVC9420SLSS

CONTACT **FIRSTBUILD.COM/INVENTIONS/MONOGRAM-HOOD-DUCT-COVER/** TO PURCHASE A HOOD DUCT COVER TO PAIR WITH YOUR MONOGRAM HOOD.

For brass hood only, unlacquered brass is a living finish that requires additional use and care. See Keeler Brass Company Product Care Card for more details.

25"

PROFESSIONAL HOODS INSTALLATION

MONOGRAM Designer collection

This hood is designed to be installed onto a wall. Install this hood 30" minimum to 36" maximum above the cooking surface. **NOTE**: Clearances may vary due to type of cooking product and local codes. Check with local inspectors to be sure standard is applicable.

BACK VENT INSTALLATION



In this installation, the ductwork running from the top of the hood will be concealed in the soffit or upper cabinetry.



In this installation, the ductwork running from the back of the hood goes directly into the wall.